


## How to open the 4m on the Yaesu FT-710?

- 1. Turn OFF the FT-710 AESS;
- 2. Press and hold the [FINE] and [MODE] keys while turning ON the transceiver, keep the buttons pressed for 1 sec.;
- 3. Release the buttons and the FT-710 AESS will turn OFF by itself and then turn back ON automatically;
- 4. The radio is now enabled for TX on the 5.250000 MHz 5.406500 MHz and 70.000000 MHz 70.499999 MHz.



The modification for TX continuous coverage on the FT-710 AESS is not yet available, we do not know as of now whether it will be made available anytime soon.

